

Meet your phone.

SAMSUNG
Galaxy Note8

Para la versión en español, visite
verizonwireless.com/Support

verizon✓

About your phone



NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.




Setting up your phone

Your phone already has a SIM card installed.

Optional: Insert the microSD card

1. With the screen facing up, insert the tool that came with your phone into the hole on the SIM/microSD™ card tray to open it.
2. Carefully slide out the tray.
3. Insert the microSD card into the tray with the gold contacts facing down (as shown).
4. Carefully slide the tray back into place.

NOTE: microSD™ card sold separately.



Charge the phone

Before turning on your phone, charge it fully.

Your phone comes with an Adaptive Fast Charging charger and a USB cable. Plug the smaller end of the cable into the USB/charger port on your phone and the larger end into the charger. Then plug the charger into an electrical outlet.



CAUTION: Use only charging devices that are approved by Samsung. Samsung accessories are designed for your device to maximize battery life. Using other accessories may void your warranty and may cause damage.

Using your phone

Turning your phone on/off

To turn your phone on, press and hold the **Power/Lock** button.

To turn your phone off, press and hold the **Power/Lock** button. Then tap **Power off** > **Power off**.

Locking/Unlocking the screen

To turn on your screen, press the **Power/Lock** button and then swipe up on the screen to unlock it.

To turn your phone off, press and hold the **Power/Lock** button. Then tap **Power off** > **Power off**.

For added security, choose one of these other locking features:

- **Fingerprint Scanner:** Use your fingerprint to unlock your phone.
- **Face Recognition:** Have your phone unlock when it recognizes your face.
- **Iris Scanner:** Use your eyes to unlock your phone.

 >  From the Home screen, swipe up for **Apps** and then tap **Settings** > **Lock screen and security** and choose your screen lock type. Then follow the onscreen instructions.

NOTE: The Iris Scanner is not intended to be used as a medical device and the biometric data collected and stored locally by the mechanism is not intended to be used for any diagnostic, therapeutic, or preventative purposes. Please follow all instructions for use of this feature. For more information, refer to the online support content or visit: samsung.com/us/irisscanner.


Home screen mode

You can select one of the two modes: Easy or Standard. Instructions in this guide are written using Standard mode.


Standard mode is for users who are familiar with Android™.

Easy mode is a simplified experience for the first-time smartphone user.

1.  >  From the Home screen, swipe up for **Apps** and then tap **Settings** > **Easy mode**.
2. Choose the mode you want to use and tap **APPLY**.



Standard mode





Easy mode

Edge screens

Edge screens deliver always-on access to text, email, notifications, news and more.

To choose which Edge screen you want to use and customize the information it displays:

 >  From the Home screen, swipe up for **Apps** and then tap **Settings** > **Edge screen**.



Edge screen

Tap the Edge handle to view Edge panels.




Using your phone

Hello Bixby

To launch **Hello Bixby**, press the **Bixby** button.

Hello Bixby lets you quickly set reminders, use your voice to enter text, and access content on your phone and on the Internet.



S Pen

The S Pen™ enables fast and precise input, providing the most natural writing experience.



Remove the S Pen to open Air command, for quick access to handy tools. To remove the S Pen, push the S Pen inward, and then pull it out.



Using your S Pen

Express yourself. Write and draw directly into emails or the calendar, as well as Word, Excel, PowerPoint, and PDF documents. Capture your ideas in Notes and even write a note on the back of a picture.

Create note: Create customized notes.

View all notes: View all notes created.

Smart select: Outline and crop anything on the screen and freely edit or share with others.


Screen write: Capture a screen image and write or draw on it.

Live message: Create live messages and GIFs.

Translate: Hover the S Pen over a word to view its definition and pronunciation.

Bixby Vision: Shop and discover images, products, and places.

Add shortcuts: Select an app or function to open or turn on using Air command.



Apps

Find new apps to download and install on your device.



Play Store: Download new apps from the Google Play store.

Visit **[Play.Google.com/Store/Apps](https://play.google.com/store/apps)** to learn more.



Galaxy Apps: view and download Samsung apps that are optimized for use with Galaxy devices.


Visit **samsung.com/global/galaxy/apps/galaxy-apps** to learn more.

Copying content from your old phone

For help transferring contacts, photos and other content from your old phone, visit **verizonwireless.com/Cloud**.

Or, transfer content using Smart Switch and the USB connector that came with your phone.

 >  From the Home screen, swipe up for **Apps** and then tap **Settings > Backup and reset > Smart Switch**.



Learning more



Use the Help feature to access your device user manual and other information on how to use your phone, including:



Making calls



Voicemail



Sending texts



Getting apps



Taking photos



Accessibility settings



To open the **Help** feature, from the Home screen swipe up for **Apps** and then tap **Settings > Help**.



From your computer, visit **[verizonwireless.com/Support](https://www.verizonwireless.com/Support)**.



Download a User Guide from **[verizonwireless.com/Support](https://www.verizonwireless.com/Support)** or call **888.987.HELP** to order a copy.

Managing your account



My Verizon Mobile app

Manage your account, track your usage, edit account information, pay your bill and more.



International travel

For features and rates when outside the US, visit:

verizonwireless.com/International.



Customer service

Call **800.922.0204**

Twitter **@VZWSupport**

Additional information

Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, ask your service provider or phone retailer.

Samsung and Galaxy Note8 are trademarks of Samsung Electronics Co., Ltd. Android, Google, the Google logo and Google Play are trademarks of Google Inc. Screen images simulated. Appearance of device may vary.